

HIPBELT POCKET INSTALLATION



ONE PLANET Hipbelt Pockets can be easily attached to the Exact Fit Mid and Exact Fit harnesses. designed to contour with your hipbelt, they can be fitted to your preferred side using the four webbing loops on the back.



SETUP INSTRUCTIONS

Choose which side you would prefer your pocket on.



1 Start by unthreading the main 38mm hipbelt webbing from the hipbelt side buckle. Ensure the webbing remains threaded through the hipbelt centre buckle.



2 Turn the buckle 90 degree's.



3 Thread the hipbelt buckle through the pocket's front loop to correctly locate your hipbelt pocket.



4 Turn the buckle back 90 degrees to the front facing position.



5 Re-thread the hipbelt webbing through the side buckle.



6 To secure the rear half of your pocket: Unthread the hipbelt stabilising strap.



7 Thread the strap through the rear two hipbelt pocket loops.



8 Then re-thread the stabilising strap.



9 Your hipbelt pocket should sit securely on the belt as shown.



650 Somerville Road
Sunshine West VIC 3020
P | 03 9311 5244
E | sales@oneplanet.com.au

Any further questions?

If you have any further questions or you would like to see other products in our range, visit [oneplanet.com.au](https://www.oneplanet.com.au)